

ATSC Channel Center Frequency Chart

Channels- 54 to 1002 MHz

Channel Number	Center Frequency MHz	Channel Number	Center Frequency MHz	Channel Number	Center Frequency MHz
2	57	31	575	60	749
3	63	32	581	61	755
4	69	33	587	62	761
5	79	34	593	63	767
6	85	35	599	64	773
7	177	36	605	65	779
8	183	37	611	66	785
9	189	38	617	67	791
10	195	39	623	68	797
11	201	40	629	69	803
12	207	41	635		
13	213	42	641		
14	473	43	647		
15	479	44	653		
16	485	45	659		
17	491	46	665		
18	497	47	671		
19	503	48	677		
20	509	49	683		
21	515	50	689		
22	521	51	691		
23	527	52	701		
24	533	53	707		
25	539	54	713		
26	545	55	719		
27	551	56	725		
28	557	57	731		
29	563	58	737		
30	569	59	743		